

HOW TO MEASURE FOR CURTAIN POLES

Step 1: Measure the width of the window. (A)

Step 2: Add 15-25cm to each side of the window width in order to account for the curtain drawback. (B) If the space does not allow for this, please contact our Customer Services team with an image of your window and we will be able to advise.

Step 3: Please note the pole width does not include the length of the decorative finials, so make sure there is enough space to fit the finials (you can find the dimensions on the online product pages on our website). (C)

